

Statim G4 Conductivity Setup

To change the water conductivity setting go to the Technician menu and select Conductivity Setup. To adjust the H=10.0 (upper limit) reading touch the up arrow under H=10.0. The value should increase .1 μ S for each touch. After touching the arrow wait for the value to change before touching again. You can raise the level to H=15.0 but do not exceed this reading. If the CD=xx.x is above 15.0 μ S your water needs to be replaced. When finished touch the Stop button in the lower right corner until you are back at the home screen.

